



Intelligent Fingerprint Access Controller

Model: YWF-1168


Parameters

- Operating system: Real-time control of the operating system
- Dimensions: L131.6xW75xH18(mm)
- Case Material: Alloy Zinc
- Panel material: Acrylic Hardened Panel
- User capacity: Fingerprint: 300; IC card:1000; Password:1000
- Power Input: DC12V 1-2A
- Current: Static Operating Current is 80mA

/ Operating Current is 500mA

- Communication mode: Tuya Bluetooth
- Language : Simplified Chinese / English
- Access Control Function: Door Bell / Manual
- Access Mode: Password / IC card/ Living Fingerprint
- Operating Temperature: -20 ~ +50°C
- Voice Prompt: HD Humanized Voice


Dimensions




Wiring Diagram

No	Notes	Color	Function
1	+12V	Red	+ power input
2	GND	Black	- power input
3	NO	Green	Relay NO Output
4	СОМ	Gray	COM connection for relay
5	NC	Yellow	Relay NC Output
6	DO	White	Wiegand D0 Ouput
7	DI	White	Wiegand D1 Ouput
8	BELL+	Blue	External doorbell positive contact
9	BELL-	Blue	External doorbell negative contact

Connecting Diagram





LED Indicator

◆ Green Light Shines: Standby Mode

Green: Success

◆ Red: Failure

Purple: Normally Open Status

Red Light Shines Quickly: Initialization is

under processing

We create security


Menu Operation

1. Operating Instructions

- In standby mode, enter "*, #" to enter the system menu. In the initial states and non-administrator states, enter "*, #" to directly enter the system menu;
- number of system administrators are 4 , fingerprint and passwords can be registered freely.
- Press and hold the administrator's fingerprint for 3 seconds or swipe the administrator card three times to enter the state of adding ordinary users;
- Any user can enter "9, #" within 3 seconds after unlocking to enter the normally open state. To access the item by any method in the normally open state, the item will automatically exit the normally open state.

2. System Menu Diagram

The system uses full voice navigation, users can enter corresponding numbers according to voice prompt to set functions. It supports navigation settings in both Chinese and English.



3. Normally Open Mode

- Any user can enter "9, #" within 3 seconds after unlocking to enter the normally open state. To access the item by any method in the normally open state, the item will automatically exit the normally open state
- LED indicator is purple in normally open state

Tuya Blutooth Settings

- 1、Download Tuya APP
- Use phone to scan the below QR code to download APP, or search and download the APP in the APP market



Tuya APP

2. Registration And Login


◆ Enter Tuya smart app, click the login button button, enter the account and log in. The user need to register first before login





3. Add Device

◆ Enter APP and add device by clicking the "+" at the top-right, enter " add device" page, turn on Bluetooth, the android phone will be placed on the top of the homepage and will automatically search for devices for pairing.



4. Temporaty Unlocking Setting

■ Enter homepage, click "Temporary" at the bottom to enter "Add temporary lock" page, set the time limit or a single time to unlock.



5. User Management

■ Enter homepage, click "Family" at the bottom-left to enter "family -Associated unlock "mode, click "+" at the top-right to set device code and input other user's data

